


# DURATRANS GEARCASE PARTS



# DURATRANS GEARCASE PARTS



<i>Illustration #</i>	<i>Part #</i>	<i>Description</i>
1	285037	Duratrans Shaft Complete
2	<b>352430</b>	<b>Shaft, Sleeve, SS (2)</b>
3	350659	Gearcase Cover
4	<b>285672</b>	<b>Kit -- Spring, Seal &amp; Shield</b>
5	355469	Agitator Shaft Gear
6	<b>285036</b>	<b>Duratrans Shaft Only</b>
7	285205	Thrust & Ball Bearing
8	<b>75073</b>	<b>Sector Gear</b>
9	775596	Dowel Pin
10	<b>660883</b>	<b>Sector Gear Bearing</b>
11	354513	Drive Pinion Bearing
12	<b>356512</b>	<b>Bolt (2) 5/16-24 x 1-1/8"</b>
13	62735	Bolt (4) 5/16-24 x 3/4"
14	<b>95089</b>	<b>Gearcase Gasket</b>
15	16024	Pinion Washer
16	<b>84467</b>	<b>Drive Pinion (Incl. #'s 15 &amp; 17)</b>
17	90369	Retainer Ring
18	<b>16015</b>	<b>Gear Fork Spring</b>
19	80398	Not Available
20	<b>76577</b>	<b>No Longer Available</b>
21	285765	Main Gear Retainer Ring
22	<b>95083</b>	<b>Main Gear Retainer Washer</b>
23	353397	Main Drive Gear
24	<b>362906</b>	<b>Gearcase Bottom</b>
25	355613	Bolt - 5/16-24 x 1-3/4"